CHECKLIST

Laminate Underlay Checklist

- [ ] Check your subfloor material: concrete or timber
- [ ] Read the laminate manufacturer's underlay specification
- [ ] Choose combination underlay for concrete ground floors
- [ ] Choose acoustic underlay for timber upper floors
- [ ] Sweep and vacuum the subfloor before laying anything
- [ ] Store underlay rolls flat in the room for a day before fitting
- [ ] Lay sheets edge to edge with no overlap or gap
- [ ] Tape all seams if using moisture barrier film
- [ ] Trim each sheet square at walls
- [ ] Lay laminate immediately after underlay is down