CHECKLIST

Inward-opening window dressing checklist

- [ ] Open the window fully and measure how far the sash projects into the room
- [ ] Mark where the pole, track or blind must sit to clear the swing path
- [ ] Measure the reveal width and height in three places and use the smallest figures
- [ ] Choose a treatment that rolls up, folds away or stacks on the wall outside the frame
- [ ] Check that handles and trickle vents have clearance when the window moves
- [ ] Fit brackets outside the swing arc and test the window opens fully without catching
- [ ] Add spacers behind poles if handles touch the hanging fabric