CHECKLIST

Wall Preparation After Wallpaper Removal

- [ ] Wash the entire wall with warm soapy water to remove adhesive residue
- [ ] Let the wall dry completely before applying filler
- [ ] Fill all holes and cracks, slightly overfilling each one
- [ ] Sand filled areas and the surrounding wall to a uniform texture
- [ ] Wipe away sanding dust with a damp cloth
- [ ] Prime any bare plaster or large repair patches
- [ ] Inspect the wall under a raking light for remaining flaws
- [ ] Fix any imperfections before opening the paint tin